

**Description**

\*

**Swiss 2 Conductor Plugs 10 Amp. 250 Volt**

\*

Connector No.

- |   |   |                |
|---|---|----------------|
| 1 | Swiss Plug , 2nd. end remove outer jacket and strip             |                |
| 2 | Swiss Plug , 2nd. end Connector IEC 320 - C17, 10 amp.          | WS - 002 - E   |
| 3 | Swiss Plug , 2nd. end Connector IEC 320 - C17 90° right, 10 amp | WS - 029 - E R |
| 4 | Swiss Plug , 2nd. end Connector IEC 320 - C17 90° left, 10 amp. | WS - 029 - E L |

\*

**Swiss 3 Conductor Plugs 10 Amp. 250 Volt**

\*

Connector No.

- |    |   |              |
|----|---|--------------|
| 1  | Swiss Plug , 2nd. end remove outer jacket and strip             |              |
| 2  | Swiss Plug , 2nd. end Connector IEC 320 - C5, 2.5 amp.          | WS - 083     |
| 3  | Swiss Plug , 2nd. end Connector IEC 320 - C5 90°, 2.5 amp       | WS - 083-1   |
| 4  | Swiss Plug , 2nd. end Connector IEC 320 - C13, 10 amp           | WS - 002-2   |
| 5  | Swiss Plug , 2nd. end Connector IEC 320 - C13 90°right, 10 amp. | WS - 002-A R |
| 6  | Swiss Plug , 2nd. end Connector IEC 320 - C13 90°left, 10 amp.  | WS - 002-AL  |
| 7  | Swiss Plug , 2nd. end Connector IEC 320 - C13 90°front, 10 amp  | WS - 002-B   |
| 8  | Swiss Plug , 2nd. end Connector IEC 320 - C15, 10 amp.          | WS - 002C    |
| 9  | Swiss Plug , 2nd. end Connector IEC 320 - C15 90° right, 10 amp | WS - 002C R  |
| 10 | Swiss Plug , 2nd. end Connector IEC 320 - C15 90° left, 10 amp  | WS - 002C L  |